

Ignition Timing.txt

Jan Buchwald

Joined: 31 May 2004

Posts: 64

Location: Danmark

Posted: Tue Jun 01, 2004 8:22 am      Post subject: Status on "gearchange" Brum  
(old web)

-----  
With the help from several, thank you.

I found a shim on top of the float that lowered the level 1,5 mm.

By adding a tacho, I realised, that my senses said "change gear" at 3000 rpm.

From measures given by Roger, and some calculation, I found that 35 degrees is 70 mm measured on the circumference of the flywheel. With a paintmarker and a strobe, I got the ignition right. The distributor gives "max" at 2900 rpm (says the Lucas manual)

By the way, Lucas DKX2A distributor is made in at least 4 different versions.

Jan B